## **#THESUNCAREPROJECT (US20206)**

Your unique skin's personal bodyguard

_			
A	Water(Aqua) Glycerin		38.00% 3.00%
	AQUAXYL™ (Xylity glucoside, Anhydroxylitol, Xylitol)	Seppic	3.00% <b>1.50</b> %
	FLUIDIFEEL™ EASY (Lauryl Glucoside, Myristyl Glucoside, Polyglyceryl-6	Seppic	3.00%
	Laurate) Phenylpropanol, Propanediol, Caprylyl Glycol, Tocopherol	Ashland	1.00%
В	MONTANOV™ 82 (Cetearyl Alcohol, Coco-Glucoside) DUB ESTOLINE (Ethylhexyl polyhydroxystearate) DUB HELIOPTIMA (Diisopropyl Adipate, Propylene Glycol Dicaprylate/Dicaprate, C12-15 Alkyl Benzoate, Diisopropyl Sebacate) Polyhydroxystearic Acid Hydrogenated Palm Oil, Saccharum Officinarum (Sugarcane) Extract Zinc Oxide	Seppic Stearinerie Dubois Stearinerie Dubois	2.00% 2.00% 21.00%
		Phoenix Chemical Symrise Symrise	1.00% 3.00% 22.00%
С	<b>ANTILEUKINE 6™</b> (Caprylic/Capric Triglyceride, Laminaria Ochroleuca Extract)	Seppic	2.00%
D	<b>SEPINOV™ WEO</b> (Hydroxyethyl Acrylate/Sodium Acryloyldimethyl Taurate Copolymer)	Seppic	0.50%

Aspect: Very smooth white cream

pH: 8.3 / VISCOSITIES: 1M at RT: 2790,000 cps mPa.s Brookfield LV96 V0.3 Recovery at RT (after 1M at 45°C): 43,741 mPa.s Brookfield LV96 V0.3.

STABILITY: 3M at RT & 45°C, F/T 3 cycles (-5°C/+40°C).

FORMULATION ADVICES: Laboratory scale - 300 grams - homogenizer & Sweeper
Combine phase A and heat to 85C. Combine phase B and heat to 85C and then homogenize to help disperse zinc oxide. Disperse phase C and D into phase B and heat to 85C. Combine phase A and BCD together and homogenize for 4 minutes at 4,000rpm. Cooldown the batch with sweeper blade to ambient temperature.



All information contained herein is intended merely to demonstrate the utility of Seppic products, and should not be construed as granting license to practice any compositions or methods covered by a patent or a patent application or efficacy or tolerance. All information nominating any composition of mentious covered by a patient application of enticky of tolerance. All information contained in this specific technical documentation is believed to be accurate and has been set up by Seppic according to its own described methods and processes. Seppic however does not assume any liability or risks involved in the use of its products for the preparation and the assessment of the hereinabove formulation since the condition of use are beyond its control. Seppic customer must insure that the duplication of the hereinabove formulation is not infringing any intellectual property rights and that it complies with any regulatory status. Formula only for demonstration purposes. Seppic has not tested efficacy, toxicology and safety of this formulation if not mention.

**SEPINOV™ WEO,** EO-free polymer, thickens

MONTANOV™ 82 and FLUIDIFEEL™ EASY

**DUB ESTOLINE** provides a comfortable skin

**DUB HELIOPTIMA** gives a smooth skin feel

ANTILEUKINE 6™ acts as a shield to





LIGHT SKIN-FEEL

SHIELD AGAINST UV RAYS